NWG/RFC 25

Steve Crocker
30 October 69

No High Link Numbers

Because it may be desirable to reserve one or more link numbers for instrumentation purposes, and because 256 link numbers are many more than are needed, we suggest that no link number over 63 be used. At UCLA, we will implement our tables to take advantage of this limitation. We also note that 32 may be even more realistic, but 64 is certainly sufficient.